

Installation

Model specific instructions

For:

Yamaha XT1200Z Super Ténéré

These instructions are a model specific add-on to the general BoosterPlug installation instructions.

The general BoosterPlug installation instructions can be found in the "Downloads" section on the BoosterPlug.com website:

http://www.boosterplug.com/shop/cms-downloads.html

Installation Tips

- Install the BoosterPlug module as per the general installation papers.
- The picture below should help you locate the AIT sensor where the BoosterPlug is installed.
- Remove the seat and the two fairing panels one on each side of the gas tank.
- Remove the bolt on each side of the tank, and lift the front end of the tank slightly
- Now you can access the AIT sensor which is located on the right hand side of the bike in the air filter box under the gas tank.
- See pictures below for the details.
- You have several choices for the BoosterPlug sensor location, but our favorite place is near the steering head or under the head light. Next to the airbox snorkel air intake hole is another very good spot.
 - Just stick to the simple rules in the general installation instructions for placing the external sensor, and you'll be fine.

Pictures

For:

Yamaha XT1200Z Super Ténéré







