



Installation

Model specific instructions

For:

- KTM 1050 Adventure
- KTM 1090 Adventure (2017-up)
- KTM 1190 Adventure
- KTM 1190 Adventure R
- KTM 1290 Super Adventure (2015-2016)
- KTM 1290 Super Adventure (2017-up)

These instructions are a model specific add-on to the general BoosterPlug installation instructions.

The general BoosterPlug installation instructions can be found in the "Downloads" section on the BoosterPlug.com website:

<http://www.boosterplug.com/shop/cms-downloads.html>

Installation Tips

- Install the BoosterPlug module as per the general installation papers.
- The pictures below should help you locate the AIT sensor where the BoosterPlug is installed.
- You need to remove the gas tank to get access to the AIT sensor.
- One of the connector cables on the BoosterPlug for the Adventure is made longer than seen in the webshop pictures.
 - No worries - This is to let you place the BoosterPlug module behind the air filter box, as there's not much room between the gas tank and the air box.

Pictures

For:

- KTM 1050 Adventure
- KTM 1090 Adventure (2017-up)
- KTM 1190 Adventure
- KTM 1190 Adventure R
- KTM 1290 Super Adventure (2015-2016)
- KTM 1290 Super Adventure (2017-up)

