



Installation

Model specific instructions

For:

- **Yamaha FJR1300 (2013-up)**

These instructions are a model specific add-on to the general BoosterPlug installation instructions.

The general BoosterPlug installation instructions can be found in the "Downloads" section on the BoosterPlug.com website:

<http://www.boosterplug.com/shop/cms-downloads.html>

Installation Tips

- Install the BoosterPlug module as per the general installation papers.
- The pictures below should help you locate the AIT sensor where the BoosterPlug is installed.
- Follow these steps to install the BoosterPlug
 1. Remove the plastic coverings on the windscreen and slide the covers up and out of their slots
 2. Remove the 6 black plastic screws that hold the windscreen in place and remove the windscreen.
 3. Remove the 4 capscrews that hold the windscreen bracket and remove
 4. Remove the 2 capscrews under the plastic air funnel.
 5. Remove the top 2 capscrews located at the top left and right of the gauge cluster panel
 6. Remove the plastic panel by lifting from the top of the gauge cluster and carefully removing as to not break the plastic snap pieces.
 7. Locate the AIT sensor at the top left just under the gauge cluster
 8. Unplug the AIT sensor and connect the Booster plug and move the probe into the airstream in the air intake funnel so it is next to the Yamaha AIT sensor

Pictures



