

Installation

Model specific instructions

These instructions are a model specific add-on to the general BoosterPlug installation instructions.

The general BoosterPlug installation instructions can be found in the "Downloads" section on the BoosterPlug.com website:

http://www.boosterplug.com/shop/cms-downloads.html

For:

Derbi Mulhacén 659

Installation Tips

- Install the BoosterPlug module as per the general installation papers.
- The picture below should help you locate the AIT sensor where the BoosterPlug is installed.
 - The AIT sensor is found in the front of the air filter box, on the right hand side, below the throttle valve housing.
- You have several choices for the BoosterPlug sensor location, but our favorite place is near the steering head or under the head light.
 Next to the airbox snorkel air intake hole is another very good spot.
 - Just stick to the simple rules in the general installation instructions for placing the external sensor, and you'll be fine.

Pictures

