



Model specific instructions

For:		
•	KTM 1190 RC8	
•	KTM 1190 RC8 R	

These instructions are a model specific add-on to the general BoosterPlug installation instructions.

The general BoosterPlug installation instructions can be found in the "Downloads" section on the BoosterPlug.com website:

http://www.boosterplug.com/shop/cms-downloads.html

Installation Tips

- Install the BoosterPlug module as per the general installation papers.
- The pictures below should help you locate the AIT sensor where the BoosterPlug is installed.
- The Sensor is located in the bottom of the air filter box, just behind the steering head.
- You need to remove the air filter box to install the BoosterPlug.
- The 10 minutes BoosterPlug installation claim does probably not hold on the RC8 and RC8R it does take some time to remove the air filter box, but race bikes was never made to please the mechanic

Pictures

