



# Installation

Model specific instructions

For:

- KTM 790 Duke
- KTM 790 Adventure
- KTM 790 Adventure R

These instructions are a model specific add-on to the general BoosterPlug installation instructions.

The general BoosterPlug installation instructions can be found in the "Downloads" section on the BoosterPlug.com website:

<http://www.boosterplug.com/shop/cms-downloads.html>

## Installation Tips

- Install the BoosterPlug module as per the general installation papers.
- The pictures below should help you locate the AIT sensor where the BoosterPlug is installed. (The red circle)
- The AIT sensor is located in the top of the air filter box - just remove the seat to access the AIT sensor.
- **NOTE:** On the Adventure models, one of the connector cables on the BoosterPlug is made longer than seen in the webshop pictures. This is to let you relocate the BoosterPlug module as there's not much room between the seat and the air box.
- You have several choices for the BoosterPlug sensor location, but our favorite places are near the steering head, under the head light, or next to the airbox snorkel air intake hole.
  - Just stick to the simple rules in the general installation instructions for placing the external sensor, and you'll be fine.

## Pictures

For:

- KTM 790 Duke



For:

- KTM 790 Adventure
- KTM 790 Adventure R

