



Installation

Model specific instructions

For:

- Moto Guzzi California 1400 Custom
- Moto Guzzi California 1400 Touring
- Moto Guzzi Audace
- Moto Guzzi Eldorado
- Moto Guzzi MGX-21 Flying Fortress

These instructions are a model specific add-on to the general BoosterPlug installation instructions.

The general BoosterPlug installation instructions can be found in the "Downloads" section on the BoosterPlug.com website:

<http://www.boosterplug.com/shop/cms-downloads.html>

Installation Tips

- The pictures below should help you locate the AIT sensor where the BoosterPlug is installed.
- The AIT sensor is in the top of the balancer chamber that is located between the throttle valve housing and cylinder heads.
- Remove the gas tank back to get access to the AIT sensor.
- Install the BoosterPlug module as per the general installation papers.
- You have several choices for the BoosterPlug sensor location, but our favorite place is near the steering head or next to the airbox intake snorkel. Just stick to the simple rules in the general installation instructions for placing the external sensor, and you'll be fine.

Pictures

