



Installation

Model specific instructions

For:

- [Triumph Speed Triple](#)

These instructions are a model specific add-on to the general BoosterPlug installation instructions.

The general BoosterPlug installation instructions can be found in the "Downloads" section on the BoosterPlug.com website:

<http://www.boosterplug.com/shop/cms-downloads.html>

Installation Tips

- Install the BoosterPlug module as per the general installation papers.
- The pictures below should help you locate the AIT sensor where the BoosterPlug is installed.
- Remove the seat (Yellow circle - Picture 1)
- Lift the front end of the tank (Yellow circle - Picture 2 +3)
- The red circle will show you the location of the AIT sensor
- Note: The BoosterPlug for the Speed Triple have a longer cable for the AIT connector than shown on our website - this is just to let you relocate the square BoosterPlug box, because there's not much room between the air filter box and the tank.
- You have several choices for the BoosterPlug sensor location, but our favorite place is near the steering head or under the head light. Next to the airbox snorkel air intake hole is another very good spot.
 - Just stick to the simple rules in the general installation instructions for placing the external sensor, and you'll be fine.

Pictures

