



# Installation

Model specific instructions

For:

- [Honda FJS400 Silver Wing](#)
- [Honda FJS600 Silver Wing](#)

These instructions are a model specific add-on to the general BoosterPlug installation instructions.

The general BoosterPlug installation instructions can be found in the "Downloads" section on the [BoosterPlug.com](http://www.boosterplug.com) website:

<http://www.boosterplug.com/shop/cms-downloads.html>

## Installation Tips

- Install the BoosterPlug module as per the general installation papers.
- The pictures below should help you locate the AIT sensor where the BoosterPlug is installed.
- The AIT sensor is located in the rear end of the air filter box.
- You have several choices for the BoosterPlug sensor location, but our favorite place next to the airbox snorkel air intake hole.
  - Just stick to the simple rules in the general installation instructions for placing the external sensor, and you'll be fine.

## Pictures

For:

- [Honda FJS400 Silver Wing](#)
- [Honda FJS600 Silver Wing](#)

