



Installation

Model specific instructions

For:

- **Suzuki DL250 V-Strom**
(2017 and newer)
(L7 models and newer)
- **Suzuki GSX250R**
(2017 and newer)
(L7 models and newer)
- **Suzuki Inazuma 250**
(Suzuki GW250)
(Suzuki GSR250)

These instructions are a model specific add-on to the general BoosterPlug installation instructions.

The general BoosterPlug installation instructions can be found in the "Downloads" section on the BoosterPlug.com website:

<http://www.boosterplug.com/shop/cms-downloads.html>

Installation Tips

- Install the BoosterPlug module as per the general installation papers.
- The pictures below should help you locate the AIT sensor where the BoosterPlug is installed.
- The AIT sensor is located in the front/bottom of the air filter box (See pictures below).
- You have several choices for the BoosterPlug sensor location, but our favorite place is near the steering head or under the head light. Next to the airbox snorkel air intake hole is another very good spot.
 - Just stick to the simple rules in the general installation instructions for placing the external sensor, and you'll be fine.

Pictures

For:

- **Suzuki DL250 V-Strom** (2017 and newer) (L7 models and newer)
- **Suzuki GSX250R** (2017 and newer) (L7 models and newer)
- **Suzuki Inazuma 250 (Suzuki GW250) (Suzuki GSR250)**

