



Installation

Model specific instructions

For:

- Aprilia SL 750 Shiver
- Aprilia SL 750 Shiver GT
- Aprilia SMV 750 Dorsoduro
- Aprilia SL 900 Shiver
- Aprilia SMV 900 Dorsoduro

These instructions are a model specific add-on to the general BoosterPlug installation instructions.

The general BoosterPlug installation instructions can be found in the "Downloads" section on the BoosterPlug.com website:

<http://www.boosterplug.com/shop/cms-downloads.html>

Installation Tips

- Install the BoosterPlug module as per the general installation papers.
- The pictures below should help you locate the AIT sensor where the BoosterPlug is installed.
- You must remove the gas tank to get access to the AIT sensor.
- The AIT sensor is located in the top of the air box. On the right hand side, just behind the ignition key switch.
- NOTE: On the Shiver models, you do not have to remove the gas tank. Just release the two screws in the front of the tank and lift the tank carefully approx. 10 cm.
 - Then you should be able to reach the AIT sensor on the right hand side of the bike, below the tank.
- You have several choices for the BoosterPlug sensor location, but our favorite place is near the steering head or under the head light. Next to the airbox snorkel air intake hole is another very good spot.
 - Just stick to the simple rules in the general installation instructions for placing the external sensor, and you'll be fine.

Pictures

For:

- Aprilia SL 750 Shiver
- Aprilia SL 750 Shiver GT
- Aprilia SMV 750 Dorsoduro
- Aprilia SL 900 Shiver
- Aprilia SMV 900 Dorsoduro

