



# Installation

Model specific instructions

For:

- Husqvarna 401 Vitpilen
- Husqvarna 401 Svartpilen
- Husqvarna 701 Vitpilen
- Husqvarna 701 Svartpilen

These instructions are a model specific add-on to the general BoosterPlug installation instructions.

The general BoosterPlug installation instructions can be found in the "Downloads" section on the BoosterPlug.com website:

<http://www.boosterplug.com/shop/cms-downloads.html>


## Installation Tips

- Install the BoosterPlug module as per the general installation papers.
- The picture below should help you locate the AIT sensor where the BoosterPlug is installed.
  - On the 401 Vitpilen and 401 Svartpilen, the AIT sensor is found in front of the air filter box, on the right hand side of the bike.
  - On the 701 Vitpilen and 701 Svartpilen, The AIT sensor is located in the air tube between the air filter box and the throttle valve housing.
- You have several choices for the BoosterPlug sensor location, but our favorite place is near the steering head or under the head light. Next to the airbox snorkel air intake hole is another very good spot.
  - Just stick to the simple rules in the general installation instructions for placing the external sensor, and you'll be fine.

## Pictures

For:

- Husqvarna 401 Vitpilen
- Husqvarna 401 Svartpilen



For:

- Husqvarna 701 Vitpilen
- Husqvarna 701 Svartpilen

