



Installation

Model specific instructions

For:

- Yamaha FZ8
- Yamaha FZ8 Fazer

These instructions are a model specific add-on to the general BoosterPlug installation instructions.

The general BoosterPlug installation instructions can be found in the "Downloads" section on the BoosterPlug.com website:

<http://www.boosterplug.com/shop/cms-downloads.html>

Installation Tips

- Install the BoosterPlug module as per the general installation papers.
- The picture below should help you locate the AIT sensor where the BoosterPlug is installed.
 - **WARNING !** The BoosterPlug is not a 10 minute install on the FZ8 as you need to remove the air filter box to access the AIT sensor. It's not rocket science, but it takes some time.
- Remove the inner fairing panel (FS8 Fazer only - upper left picture)
- Remove the front gas tank cover and lift the gas tank.
- Remove the air filter box to access the AIT sensor that is located in front of the air filter box, inside the frame.
- The External sensor on the BoosterPlug is already in the right spot, so you just need to secure it with a zip-tie to avoid it from flopping around.

Pictures

For:

- Yamaha FZ8
- Yamaha FZ8 Fazer

