



# Installation

Model specific instructions

For:

- [Yamaha MT-07](#)
- [Yamaha MT-07 Moto Cage](#)
- [Yamaha MT-07 Tracer](#)
- [Yamaha XSR700](#)

These instructions are a model specific add-on to the general BoosterPlug installation instructions.

The general BoosterPlug installation instructions can be found in the "Downloads" section on the [BoosterPlug.com](http://www.boosterplug.com) website:

<http://www.boosterplug.com/shop/cms-downloads.html>

## Installation Tips

- Install the BoosterPlug module as per the general installation papers.
- The picture below should help you locate the AIT sensor where the BoosterPlug is installed.
- Remove the right hand side covers over the gas tank. (Marked in yellow on the pictures to the left)
- The AIT sensor is located in the front of the gas tank. (Marked in red)
- The External sensor on the BoosterPlug is already in the right spot, so you just need to secure it with a zip-tie to avoid it from flopping around.

## Pictures


For:

- [Yamaha MT-07](#)
- [Yamaha MT-07 Moto Cage](#)




For:

- [Yamaha MT-07 Tracer](#)



For:

- [Yamaha XSR700](#)



For:

- [All MT-07 models](#)

